


DDC-2000 Traktor Functions (2 Decks + 2 Sample Decks)



No.	Control Element	Function 1	Function 2 (Shift +)
1	AUTO LOOP	Loop Size	Loop/Cue Move
	AUTO LOOP (Button)	Loop Active	Loop/Cue Move Setup
2	FX 1 ON	Effect 1 On	X-Fader Assign Left
3	FX 2 ON	Effect 2 On	X-Fader Assign Right
4	PITCHFADER	Playback Speed	-
5	IN	Loop In/Set Cue	-
6	OUT	Loop Out	-
7	ACTIVE	Loop Active	-
8	DELETE	Delete Hot Cue/Sample	-
9	HOT CUE 1	Set/call Hot Cue 1	Beatjump +
10	HOT CUE 2	Set/call Hot Cue 2	Beatjump -
11	HOT CUE 3	Set/call Hot Cue 3	Previous Cue Point

12	HOT CUE 4	Set/call Hot Cue 4	Next Cue Point
13	SAMPLE 1/5	Load Sample from Deck	Copy Sample from Loop Recorder
14	SAMPLE 2/6	Load Sample from Deck	Copy Sample from Loop Recorder
15	SAMPLE 3/7	Load Sample from Deck	Copy Sample from Loop Recorder
16	SAMPLE 4/8	Load Sample from Deck	Copy Sample from Loop Recorder
17	KEY LOCK	Key Lock On/Off	-
18	DECK SWITCH	Select Deck A/C and B/D	-
19	DECK LED A/C	Indicates current Deck	-
20	DECK LED B/D	Indicates current Deck	-
21	SYNC	Tempo Sync	Set to Master
22/	PITCH BEND -/+	Playback speed -/+	Tempo Range -/+
23			
24	SCRATCH	Scratch On/Off	-
25	JOGWHEEL	Pitch Bend, Scratch, Cue/Loop Points	Seek Position
26	JOGWHEEL (Touch)	Scratch	-
27	JOGWHEEL (Edge)	Pitch Bend	-
28	SHIFT	Activate Funvtion 2	-
29	CUE PLAY	Cue Play Beat Tap	Cue Play Beat Tap
30	CUE	Set Cue	Jump back to start
31	PLAY/PAUSE	Play/Pause	Playback Relative Mode (DVS)
32	GAIN	Gain	-
33	HIGH	EQ High	Pan
34	MID	EQ Mid	Key Range
35	LOW	EQ Mid	Filter
36	CUE	Deck Monitoring On/Off	-
37	CHANNEL FADER	Channel Level	-
38	METER L/R	Master VU Meter	-
39	FX ENCODER	FX Dry/Wet	FX Select
	FX ENCODER (Button)	FX Panel Mode (Single/Group)	-
40	FX ON	FX Unit On/Off	-
41	FX CONTROL 1	Amount FX Parameter 1	-
42	FX 1	FX Function 1 On/Off	-
43	FX CONTROL 2	Amount FX Parameter 2	-
44	FX 2	FX Function 2 On/Off	-
45	FX CONTROL 3	Amount FX Parameter 3	-
46	FX 3	FX Function 3 On/Off	-
47	MASTER	Overall Volume	-
48	DRY/WET	Loop Dry/Wet	-
49	BROWSER	List Select Up/Down	Tree Select Up/Down
	BROWSER (Button)	Expand Browser Window	Tree Select Expand/Collapse
50	LOAD A/C	Load Song into Deck A/C	Snap Mode
51	LOAD B/D	Load Song into Deck B/D	Quantize Mode
52	CENTER ENCODER	Loop Length	-
	CENTER ENCODER (Button)	Loop Recorder (Record)	Loop Recorder (Play)
53	CROSSFADER	Crossfader between Deck A/C B/D	-
54	VIDEO X-FADER	Auto X-Fader (Left)	-
55	X-FADER LINK	Auto X-Fader (Right)	Loop Recorder Undo
56	CROSSFADER CURVE	Adjust Crossfader Curve	-
57	CUE MIXING	Select Monitoring Signal	-
58	CUE LEVEL	Adjust Monitoring Volume	-